



## Instruction of Filter Travel Bottle

### I. Brief Instruction

Filter Travel Bottle is specialized design and production aimed at increasingly serious water environment pollution, and field survival, evection, travel and various outdoors activities after breaking out tragedies, such as war, flood, cyclone, earthquake and epidemic situation, etc.

The core equipment of its purifying system——ion adsorbing minisize filter cartridge is patent product, which is developed by outer space scientists, medicine investigators and water treatment experts through more than 30years research. It is also strictly inspected and identified by Environmental Protection Agency (EPA) and America National Register Laboratory. Its quality is up to or exceeds No.42 and No.53 standards stipulated in the agreements of EPA, ANSI and NSF (No.53 standard). All materials adopted are all accorded with the foodstuff grade of Food and Drug Administration (FDA). The serial product has approved by China Province Sanitation Test for security function test.

### II. Function Test

As high technological patent product, filter travel bottle can meet your drinking purifying water requirement at any moment. This kind of filter cartridge can remove 4 kinds of main pollutant that threatens the health of human body. Its rate of elimination is up to 99.8%. To common use source of well water, river water and tap water, it can effectively eliminate.

A. Contamination: odor, chlorine, bedload and various sediments

B. Microbe pathogen: hiding bacterial element of spore, microbe remains and other spore elements;

C. Contamination: organic chemical substance, chlorobenzene polymer, trichloromethane, compounded organic substance from agriculture, detergent and pesticide, etc.

D. Deliquescent solids: aluminum, asbestos, calcium, copper, lead and hydrargyrum and other harmful heavy metal, etc.

**III. Application:** Outdoor survival after breaking out tragedies, such as flood, cyclone, earthquake and war, etc

### IV. Instruction for use:

Unscrew the bottle lid from the bottle and infuse water, then newly cover the lid. Screw down. Withdraw the nozzle on the bottle lid and extrude water.

Note: When using it in the first time, in order to cleanout remained activated carbon (no harm to human body) in the filter cartridge, need to repeat above operation 3~5times till extrude clean water, then drink.

**Specifications:** H\*L\*W=26.5\*7.5\*7.5 (For students), H\*L\*W=22\*14\*8.5 (For military)

**Gross weight:** 200g, **Net weight:** 170g (For students); **Gross weight:** 220g, **Net weight:** 180g (For military)

